



MOUNTING A BRAKE ON THE 125 RC

The front of the bottom brake structure should be about 28 mm (1.125 inches) in front of the tire. The back of the binding should be at least 38 mm in front of the tire. If you have very large boots make sure that the heel portion of the boot clears the brake. Mount the brake following the Universal brake Instructions.