

INSTRUCTIONS FOR MOUNTING V2 FENDERS ON AERO XL125 & 150

Mounting fenders is very simple. Tools required: 1 -10 mm socket wrench and 1- 5 mm Allen Hex key.

Remove the bolt from the rear wheel. Discard the washers, put on the fender as shown in the picture below. Insert the bolt and install the nut. **Do not over tighten.**

